STEADLEAF PRESS

MAKE / PERSONALIZED GIFTS & HOME ACCENTS

Create a Keepsake Shadowbox with Handcrafted Elements



150 x 150 mm panel / four 60 mm cells

10 mm border and central gutter

Arrange four lightweight handmade memory elements using a placement grid and removable attachment plan.

14 practical steps • Original diagrams and maker records

Illustrative plans — not physical test results

FREE GUIDE + PRINTABLES | STP-MAKE-F150

Before you start

A small shadowbox can preserve the meaning of a memory without risking the original object. Build a removable display panel containing paper, fabric and handmade details, then insert it into a suitable ready-made shadowbox according to the manufacturer's directions. This is an adult indoor decorative display, not an archival conservation method, structural mounting system or guarantee of protection. Use copies or replaceable handmade objects for anything irreplaceable.

Materials

A commercially made shadowbox with accessible removable backing, intact front and adequate internal space (example usable cavity 160 x 160 mm and 30 mm clear depth measured from the inner backing to the inner front); sound 150 x 150 mm cardstock mounting panel, lightweight paper motif, fabric swatch, handmade folded card accent, and a handwritten label. Use paper scissors, pencil, ruler, compatible removable paper corners or small paper tabs, and labelled craft adhesive suitable for the mounting card and replaceable objects. Keep tools and loose parts away from children and pets; do not cut, drill, remove or handle loose glass. Use a different frame if damaged.

Plan the project

Measure the actual clear cavity of the shadowbox, including backing clips, ledges and front clearance. For a usable 160 x 160 mm example, a 150 x 150 mm removable panel leaves 5 mm nominal clearance at each side. Mark four 60 x 60 mm cells on the panel with a 10 mm border and a 10 mm central gutter: x origins 10 and 80 mm and y origins 10 and 80 mm from the upper left. Centre one object in each cell: a 45 x 45 mm paper motif, a 45 x 45 mm fabric swatch, a folded card accent no larger than 50 x 50 mm, and a 50 x 20 mm title label. The example object envelopes are measured including folds and attachment. Centre objects so their edges stay inside cells. In a 30 mm clear-depth cavity, keep the combined mounting panel, attachment and object thickness to no more than 20 mm and leave at least 10 mm air clearance to the inner front. Prefer low-profile pieces, about 10 mm or less above the panel. Verify actual clearance before closing; use no pressure or improvised hardware. Removable paper corners or paper tabs attach replaceable items, not valuable originals.

Steps 1–2

1. Choose a memory and four elements

Choose one subject, such as a garden walk or family celebration. Select a paper copy or drawing, a sound fabric scrap, a lightweight folded card accent and a handwritten label. Avoid valuable originals, photographs you cannot replace, brittle objects or anything that could leak or stain.

2. Choose the shadowbox

Use a ready-made shadowbox with an intact front and access designed for changing the display. Check its instructions for opening, depth, backing and intended installation. If the front is cracked, loose or must be removed as bare glass, choose a different product.

Steps 3–4

3. Measure the clear cavity

Measure the actual accessible width and height inside the frame and the clear depth from the intended inner backing surface to the inner front. Account for retaining clips or ledges. The example is 160 x 160 x 30 mm; adapt the panel to your actual frame without forcing it.

4. Cut the removable panel

Mark a 150 x 150 mm square on suitable card for the example and cut with paper scissors. Dry fit it in the open back without touching or pressing against the front. If it binds or blocks a closure clip, trim the panel or select a suitable frame before proceeding.

Steps 5–6

5. Mark the four placement cells

From the upper-left corner mark a 10 mm border, two 60 mm cells in each direction and a 10 mm central gutter. Draw lightly so marks can be removed or hidden. Check 10 + 60 + 10 + 60 + 10 = 150 mm in both directions.

6. Make the paper motif

Draw or cut a replaceable 45 x 45 mm paper image related to the chosen memory. Keep the decoration flat and let any ink dry. If using a personal photograph, print a copy and retain the original elsewhere; do not attach the original using this guide.

Steps 7–8

7. Prepare the fabric swatch

Choose a dry, clean sound scrap and cut a visible 45 x 45 mm square. Finish fraying edges if necessary while maintaining the envelope. Do not use damp plants, scented filling, unknown dyes that may transfer, or sharp embellishments.

8. Build a small folded accent

Fold a 50 x 50 mm piece of paper in half and reopen it slightly to form a shallow raised leaf-like detail; keep the footprint within 50 x 50 mm and the height about 10 mm or less. Use a flat folded motif instead if the cavity is too shallow.

Steps 9–10

9. Write the title label

Cut a 50 x 20 mm card label and write a short title, date or memory phrase. Avoid identifying details you do not want visible. Allow ink to dry and keep the label flat.

10. Dry arrange and measure depth

Place the four pieces centred in their cells before attaching. For the example the centres are (40,40), (110,40), (40,110), (110,110) mm from the upper left. Measure the thickest assembly, including the panel and proposed attachment, against the actual clear cavity depth. Leave at least 10 mm clearance.

Steps 11–12

11. Choose removable attachments

Use suitable removable paper corners for the paper image and label, or lightweight card tabs adhered only to the replaceable mounting panel and replaceable handmade pieces. Follow adhesive instructions, avoid direct adhesive on cherished originals, and allow all bonds to cure fully. No pins, wire or heavy objects are used.

12. Attach and check the panel

Attach the four pieces following the dry arrangement. Observe whether corners or tabs lift during normal supported handling. Correct weak attachments or remove an item that cannot be held by the intended method. Do not claim a load rating or archival permanence.

Steps 13–14

13. Insert and close the frame

Follow the shadowbox manufacturer's opening and closing directions. Place the panel without pressing objects against the front, ensure clips remain unobstructed and confirm the intended clearance. Do not close a frame that resists; remove or flatten the interfering item. Display using the manufacturer's approved support method.

14. Record and care for the display

Record the memory theme, actual cavity, placement map, maximum combined thickness, attachment choices and display location. Mark DECORATIVE READY, CHANGE or HOLD. Keep away from direct strong sunlight, damp and heat, inspect periodically for loose objects and store irreplaceable originals separately.

Fix, care and preserve

Panel binds in the frame

Measure the clear cavity again including ledges and clips; trim or remake the panel.

Object touches the front

Remove or flatten the object and preserve at least 10 mm clearance in the actual assembly.

Attachment lifts

Remove the panel and repair or use a lighter replaceable element; do not close with loose parts.

Objects appear crowded

Centre smaller pieces in the cells or leave a cell blank rather than reducing all gutters.

Originality and evidence boundary

Original Steadleaf English prose, design, dimensions, artwork, diagrams and maker records. Follow actual material and tool instructions. No physical construction, cutting, sewing, adhesion, washing, durability or safety testing was performed by the publisher. Adult decorative craft only; no safety or archival certification.

Print the following pages separately if desired. For any actual-size template, disable fit-to-page scaling and check the printed calibration bar. Measured schematics are not full-size cutting patterns.

Pattern 1

Measured placement grid: 150 x 150 mm removable panel, four 60 x 60 mm cells, 10 mm outer border and central gutter. Example objects: 45 mm paper and fabric squares, 50 mm folded accent envelope, 50 x 20 mm label. Schematic; adapt to the actual cavity.



150 x 150 mm panel / four 60 mm cells

10 mm border and central gutter

Pattern 2

Attachment and depth guide: example 30 mm clear cavity, combined panel + attachment + object no more than 20 mm, leaving at least 10 mm to the inner front. Use removable corners or suitable paper tabs for replaceable pieces; no adhesive on irreplaceable originals. Schematic.



Example clear depth 30 mm



Removable paper corners hold a replaceable copy

Record 1 — Materials and plan

Record actual observations only. Use UNKNOWN or NOT CHECKED for anything you have not established.

Memory theme / four replaceable elements

Actual usable cavity W / H / depth

Mounting panel size and dry fit

Cell positions / object envelopes

Front clearance / combined thickness

Attachment methods / cure instructions

Frame manufacturer display instructions

Decision: PROCEED / CHANGE / HOLD

Record 2 — Finish and display

Record actual observations only. Use UNKNOWN or NOT CHECKED for anything you have not established.

Actual panel and object measurements

Observed attachment and edge condition

Maximum combined thickness / front clearance

Backing clips and closure condition

Display method and location

Originals stored separately / care limits

Disposition: DECORATIVE READY / CHANGE / HOLD

Date / unresolved issue