

COMPLETE FREE PRACTICAL GUIDE

An original measured adult apron with two types of ties and a front pocket

A measured, original cut-on-fold adult bib apron with simple ties, a front pocket, and a dimensioned pattern you can draft directly on fabric.

STEADLEAF PRESS | MAKE / M05 Useful Sewn Objects | STP-MAKE-F017

A useful apron begins with a readable pattern

An apron looks uncomplicated when it is hanging from a peg. The actual work lies in knowing which line to cut, where the neckline ends, how to make clean edges, and how to attach ties so the fabric lies comfortably. This guide offers one original adult-sized starting pattern with straight side and armhole segments: deliberately simple to measure and alter, rather than a universal fit claim. It can be made with hand stitching or a sewing machine appropriate to the fabric.

Your finished project: an everyday decorative bib apron with a front patch pocket, two waist ties and two neck ties. The companion drafting sheet shows a *dimensioned half-pattern*, a measurement table, a 50 mm calibration bar for the printed diagram, a strip-cutting plan and a completion record. The diagram is **not a full-size cut-out pattern**. For this large object, the reliable method is to mark the coordinates on folded fabric with a ruler. The accompanying numeric measurements, not a screen image, determine the size.

This is not flame-resistant protective clothing, kitchen heat protection, protective workwear, industrial clothing or children's sleepwear. Loose ties can catch on moving machinery or catch fire near a flame. Wear this apron only for suitable everyday, low-risk tasks. Keep it well away from open flames, burners and rotating equipment. Children should not use it unsupervised, and long ties must be kept away from children and pets.

1. Choose an appropriate fabric and check its usable size

Select stable, tightly woven cotton or linen in a weight you can comfortably sew. Extremely open weaves may fray, thick upholstery fabric may make bulky corners, and slick or stretchy fabric is harder for a first apron. This pattern assumes woven fabric with little stretch; it makes no claim to work identically with knits, coated fabrics or heavily directional prints. Choose a fabric care method compatible with the label. Prewash and press if suitable, then measure the remaining usable fabric rather than trusting its original sale length.

The illustrated layout can fit *approximately* on a piece **1500 mm wide and 1200 mm long** after any necessary prewash: the body occupies up to 700 x 760 mm, two waist strips are each 800 x 60 mm, two neck strips are each 430 x 60 mm, and the pocket blank is 340 x 230 mm. That arrangement is a planning example, **not a guarantee of yield**. Allow for selvedges, uneven cutting, pattern direction and fabric shrinkage. If your fabric is narrower, prepare a different cutting arrangement and confirm every piece fits before cutting; do not join scraps into a tie without a sound, appropriate construction plan.

Gather measuring tape, a straight ruler or long measuring edge, removable fabric marker, pins or clips, suitable sewing needle/thread or compatible sewing machine, shears designed for fabric, iron and an appropriate work surface. Store sharps safely; keep pins and needles accounted for. Follow the equipment's instructions and avoid hot-iron contact with skin.

2. Understand the original half-pattern

Draw the apron *on fabric folded along its lengthwise centre*, with the fold line vertical. The fold is the zero-x line, and measurements y increase downward from the top bib edge. The five points below describe **one half of the body cutting edge**, before hems. Connect adjacent points with straight ruler lines; do not round them or add an extra seam allowance. The outer contour is already sized to include the specified hems.

- **A (0, 0 mm):** top centre, on fold.
- **B (140, 0 mm):** outside end of top bib edge.
- **C (315, 310 mm):** waist-side corner, at the end of the slanted armhole/side opening.
- **D (350, 760 mm):** outer bottom corner.
- **E (0, 760 mm):** bottom centre, on fold.

Trace **A-B-C-D-E-A** on the folded stack; the last edge E-A is the centre fold and must **not** be cut. After cutting and unfolding, the *raw* top bib width is **2 x 140 = 280 mm** and the *raw* bottom width **2 x 350 = 700 mm**. The straight bib-to-waist diagonal is between B and C on each side. The vertical-like skirt edge runs from C to D. The original **760 mm** cutting height is measured before any hems are turned. Finished length will be shorter by the combined top and bottom hem allowances.

The top and bottom edge will each take a **double 8 mm turn** (16 mm from the edge), so the estimated finished apron length is **760 mm - 16 mm (top hem) - 16 mm (bottom hem) = 728 mm**. Hem turns at the side reduce the visible width slightly, and pressing or fabric stretch can change the real shape. These are calculated editorial dimensions, not measured results of a physically produced apron. If that size is unsuitable, do not simply increase one line without considering tie placement and pocket proportions; the next section offers a cautious adjustment.

Why this is a pattern: the coordinate set uniquely defines the body outline and the companion diagram shows the fold, cut boundary, corner coordinates, stitching/hem regions and attachment zones. A scaled diagram is a visual guide, never a template to trace at full size. No purchased pattern or third-party cutting shape is copied.

3. Plan the ties and pocket before cutting

Cut **four strips** on a suitable grain: two *waist ties* each **800 x 60 mm**, and two *neck ties* each **430 x 60 mm**. Ties are intended to be folded lengthwise into approximately **15 mm**-wide enclosed-edge tape. Each cut strip is 60 mm across: press each long raw edge approximately 15 mm inward, then fold at the centre to enclose both edges. The 60 mm strip loses 15 mm on each side to the first folds, leaving 30 mm; folding that in half gives a finished strip approximately 15 mm wide. Finish the free end with a small inward turn appropriate to your stitching; the cut lengths include that finishing turn. These are not safety-rated fasteners.

The pocket starts as a **340 x 230 mm** rectangle. Plan a double 10 mm turn on each vertical side and at the bottom, and a top edge finished with 10 mm plus 20 mm turns. Its approximate flat visible size is therefore **300 mm wide x 180 mm high**: width = 340 - 20 (left) - 20 (right); height = 230 - 30 (10 + 20 top hem) - 20 (two 10 mm bottom turns). Decide which side of the fabric should face outward. Put the pocket in the centre of the lower body, with its finished top approximately **420 mm below the top raw bib edge**. Its bottom will land roughly at **600 mm** down before adjustments. Confirm that the pocket will be inside both apron side edges and below the ties' attachment area.

The neck tie ends attach near the two outer bib corners on the *back* of the finished top hem. The waist tie ends attach at the two side corners around y = 310 mm on the *back* of the finished body. In all four places, an enclosed tie end should overlap a sound section of fabric by about 20 mm and receive a secure rectangle of stitching and an additional reinforcing pass as appropriate to the cloth. Do not attach ties only to a decorative topstitch with no enclosed or reinforced overlap.

4. Make a measured cutting plan

On a table large enough to support the fabric, measure and check the folded width available for the half-body: at least 350 mm from fold to raw outer edge for the lower portion. The folded piece needs at least 760 mm vertical space. Mark A through E on the wrong side, keeping the fold line stationary. Use a rigid ruler to connect B-C and C-D. Confirm that y = 310 mm and y = 760 mm are measured from **the same top reference**, not from the previous point. This avoids a surprisingly common cumulative-measurement error.

Before cutting, check five items: the top endpoint B is 140 mm from fold; the waist corner C is at x = 315 mm and y = 310 mm; the bottom corner D is at x = 350 mm and y = 760 mm; both halves are cut on the fold; the ties and pocket blanks still fit the remaining fabric. If any measurement is uncertain, stop and redraw rather than cutting the nearest line.

Cut only the measured outside contours through both folded layers. Do not cut along the centre fold. Cut the pocket and tie strips separately. Use fabric shears or the cutter's manufacturer instructions for equipment; never put a hand in front of a moving blade. The same drawing may be made first on craft paper, but a paper proof is optional, not a publishing or reader requirement.

5. Hem the apron body without losing the corners

Unfold the body and place it wrong-side up. Work around the outside, *excluding* the centre fold because that fold is no longer an edge. For the long slanted sections and sides, gently turn a narrow allowance of approximately **8 mm** to the wrong side, press if compatible, then turn another **8 mm** so the raw edge is enclosed. Sew along the inside fold with a straight stitch or careful hand stitch. The point where the slanted edge meets the near-vertical side is a change of angle: fold in short sections, distribute excess at the bend, and avoid making a deep cut into the fabric to force it flat.

Use the same double 8 mm hem at the top bib edge and bottom apron edge. Keep the corners flat with small mitred folds or carefully layered turns; check that neither corner traps a large lump that the needle cannot pass. A thin woven cotton allows tidier corner folds than a bulky cloth. If your material is thick, choose a suitable edge finish from its maker's guidance rather than forcing a tight roll. Never stitch with a hand under the presser foot or over a hidden pin.

This basic apron has a straightforward seam/hem finish, not an enclosed facing or professionally bound neckline. Its raw body dimensions already allow for the described turns. If you choose a different hem width, measure the result instead of claiming the finished dimensions remain unchanged.

6. Sew four enclosed-edge ties

Work on one 60 mm-wide strip at a time. Fold both long edges toward the centre by around 15 mm, then fold the strip along its centre so all long raw edges are inside. Secure with clips at intervals and stitch close to the open folded edge for its length. On the free end, fold under a short allowance before finishing; leave the *attachment end* flat until it is securely turned under or enclosed at the apron. Repeat until there are two longer waist ties and two shorter neck ties. Check that the ties are not twisted along the seam.

At each neck corner on the inside back of the bib, place a neck tie with its length pointing outward from the garment, not across the face. Fold its raw attachment end under approximately 20 mm, position well within the finished hem, and sew a reinforcement rectangle across the 15 mm width and the overlapped area. Keep the stitch lines inside the apron edge. At each y = 310 mm side corner, attach one waist tie in the same reinforced manner without bunching the diagonal-to-side transition. Stitch through strong underlying fabric, not merely a loose hem fold.

The wearer's neck must remain comfortable; ties should be adjusted or replaced if they pull, chafe or need an awkward knot. This tutorial does not claim one universal fit. Ties are not designed for force, children, machinery or flame exposure. If a wearer cannot securely adjust these ties, choose a different apron fastening design rather than over-tightening.

7. Prepare and position the pocket

Turn the pocket's top raw edge under **10 mm**, then another **20 mm**, press and stitch across to create a sturdy opening. Finish the two sides and bottom with double **10 mm** turns, taking care not to close the open top. The approximate visible rectangle is 300 x 180 mm; small changes from cloth thickness or corner treatment are normal.

Mark the centre of the apron from the original fold line and measure the planned pocket top position from the top of the raw-cut body. Lay the pocket on the apron front, right side outward, and measure to both sides so it is centred. Pin or clip without stretching. Topstitch down one side, along the bottom, and up the other side. Do not sew the upper pocket opening shut. Reinforce the top two side corners with brief extra stitching to reduce pull at the opening, without claiming a load rating. Keep the pocket well away from a stove burner, sharp tools or anything heavy enough to strain its stitches.

8. A size-adjustment worksheet, not a one-size promise

Measure the intended wearer's preferred finished length and chest coverage *before* changing the cutting pattern. To increase the original body length by **40 mm**, leave x coordinates unchanged and add 40 mm to both bottom y values: D becomes (350,800) and E becomes (0,800). The raw overall length becomes 800 mm; with the same two 16 mm edge turns, the design estimate is approximately **768 mm**. The pocket may need to move down to remain visually balanced, but the neck and waist corners stay where they are.

If you need a different chest width or tie placement, modify the outline in a controlled way using actual wearer measurements and record the new coordinates. Do not assume that a generic centimetre increase makes a safe fit for all shapes. This is a beginner construction example, not a professionally graded garment-size system. It should not be worn if the neck or waist fastening causes discomfort or constricts movement.

9. Troubleshooting without inventing a test outcome

The folded cutting shape looks asymmetric. Recheck that the fabric fold is straight and A/E are truly on it. Compare the two diagonal edges after unfolding, and correct your pattern marking before cutting a final piece. Do not hide a bad cut with an unexplained larger hem.

The slanted hem puckers at the waist corner. Use smaller pressing sections, reduce bulk carefully and sew at a steady pace. A stable cotton is easier than a thick or loosely woven textile. If the corner still will not lie flat, consider a different edge finish designed for that fabric.

A tie pulls loose. Stop wearing the apron. Examine whether the tie end was enclosed, overlapped and reinforced. Do not simply knot an unsecured strip around a weak seam and call it repaired.

The pocket leans. Check the measured centre line, pocket upper edge and both side distances. Unpick and reposition before repeated tugging makes holes in a fragile fabric.

The apron feels too short or too long. Record the wearer's actual preference, compare with the pattern length and revise bottom y coordinates. The original dimensions do not guarantee individual fit.

10. Completion record and next project

Record the fabric type, usable width and length, original or revised body coordinates, fold alignment check, tie and pocket dimensions, chosen edge turn, tie attachment method, pocket placement, comfort observations if worn, and any changes before making another. A reader may complete the dimensional worksheet even if choosing not to cut fabric. The companion sheet repeats all five half-pattern points and strip dimensions, plus a blank revision table; it is intended to prevent a full-size apron from being printed at an accidental scale.

A sensible next skill is comparing stitch strength on ordinary samples or adapting a sewing pattern for the wearer. If a cited related work is not yet published on the site, do not imply that it already has a live download link.

Sources and original-pattern note

[1] Threads Magazine, *How to Sew a Full Apron*: contextual illustration of common apron elements, hems and separate ties. This source does not supply the pattern in this guide and is not endorsed by Steadleaf Press.

Open cited source

[2] Missouri Star Quilt Co., *Apron Patterns: 6 Easy Projects to Sew*: general fabric and beginner sewing context; its patterns and imagery have not been reproduced.

Open cited source

All dimensions, coordinates, tie widths, layout and diagrams in this Steadleaf Press edition are original illustrative choices, not reproductions or adaptations of those sources. This guide presents design calculations and sewing instructions but does **not** claim a physically sewn sample, measured finished garment, tested seam performance, flame resistance or universal fit. Physical publisher trials are not required. The reader's own fit and safety judgment remains essential.

Apron half-pattern (folded fabric)

REFERENCE — NOT TRACE AS FULL SIZE



POINTS IN MILLIMETRES

x from fold / y down from bib top

A = (0, 0)

Fold meets top bib edge

B = (140, 0)

Top edge to outer bib corner

C = (315, 310)

Waist-side / diagonal corner

D = (350, 760)

Outer bottom corner

E = (0, 760)

Bottom centre on fold

CUT ON FOLD

Cut A-B-C-D-E only; NOT E-A

BODY BEFORE HEMS

280 mm top / 700 mm bottom / 760 mm high

HEMS

Double 8 mm turns: ~728 mm finished high

50 mm ruler check; the BODY IMAGE above is only 1:4 scale.

Measure full-size apron coordinates directly onto FOLDED FABRIC.

Cut list and sewing order

All dimensions in mm - measure the actual fabric before cutting

BODY	**cut once on fold**	Raw full height 760, bottom 700, top 280
WAIST TIES	**2 x 800 x 60**	Fold into ~15 mm wide enclosed tapes
NECK TIES	**2 x 430 x 60**	Fold into ~15 mm wide enclosed tapes
POCKET	**1 x 340 x 230**	After hems approximately 300 x 180
HEMS	**double 8**	Apron perimeter; double 10 for pocket sides/bottom
POCKET TOP	**10 + 20**	30 mm total upper hem allowance



Conceptual layout for 1500 x 1200 mm fabric, NOT a cut-out template.

Pale field: body + pocket. Beige bars: four ties. Verify shrinkage, selvedges and grain.

My measured apron record

Plan fabric, fit and attachment positions BEFORE cutting

Fabric type, grain and usable dimensions after care:

Original pattern or revised coordinates A-B-C-D-E:

Fold line marked; x measured FROM fold / y DOWN from top:

Cut body dimensions verified (280 / 700 / 760 mm)?

Neck tie count and length / waist tie count and length:

Pocket blank (340 x 230 mm) and final pocket placement:

Hem method for slant, side, top and bottom edges:

Tie end overlap / reinforced attachment method:

Needle, presser foot, scissors and pin-handling check:

Wearer comfort and suitability (if later worn):

Corrections before making another / final notes:

Every measurement and estimate is editorial. No physical prototype was made by Steadleaf Press.